



INTRODUCTION

EnSight provides a mechanism for users to write their own readers and have the code automatically link and execute at run-time (using a shared library). Since this is a new facility and therefore subject to potential change, usage information is only provided online. See `$ENSIGHT6_HOME/user_defined_src/readers/README` for details (including example code).

SEE ALSO

[How To Read Data](#)